

DS4+ Hardwire 4-wire Valet Switch

Steps

- 1 - While programming DS4+ on computer you need to change **RF Features**
- 2 - Under **RF features**, Change + *OUTPUT Violet/Black* to **Flash Status LED**
- 2 - Under **RF features**, Change - *INPUT Red/Blue* to **Valet Switch**
- 3 - Save and flash

Pin 8 of 22-Pin connector(DS4+) **Violet/Black** connects to **Red** wire on 4-wire valet switch

Pin 16 of 22-Pin connector(DS4+) **Red/Blue** connects to **Green** wire on 4-wire valet switch

Blue and **Black** from 4-wire valet switch connects to chassis ground

